

## RACU 5 DEACTIVATION

### NOTE

This procedure assumes that MDM N1-2 is Primary and MDM N1-1 is Secondary.

- PCS
1. INHIBIT NCS AUTORETRY  
Node 1: C&DH: MDM N1-1  
Secondary NCS MDM Node1  
'Software Control'  
  
sel MDM Utilities  
  
'Auto Retry'  
  
**cmd Inhibit Execute**  
  
√Auto Retry - Inh
  2. COMMAND N1-2 TO DIAGNOSTICS  

### NOTE

    1. Expect 'Disconnect' message on PCS.
    2. Possible PDI DECOM Fail message.

  
Node 1: C&DH: MDM N1-2  
Primary NCS MDM Node1  
  
sel Major State Transitions  
  
'N1-2'  
  
**cmd Authorize Transition to Diagnostic State Execute**  
**cmd Transition to Diagnostic State Execute**
  3. TELEMETRY RECOVERY ON OIU  
CRT SM 212 OIU  
  
BUS 4 BC - ITEM 15 EXEC (\*)  
BUS 3 RT - ITEM 10 EXEC (\*)  
Change OIU N1 Phys Dev to N1-1 - ITEM 18 +4 EXEC  
  
Wait 1 minute from diagnostic command.  
CRT Reload OIU Format 2 - ITEM 1 +2 EXEC

PCS

4. TELEMETRY RECOVERY ON PCS

On PCS attached to PDIP N1-2 port

sel icon to open PCS CDS Main Control Panel Window

√Status box - yellow

sel 'Connect to MDM'

√Status box - green

Verify 'connected to MDM' indicated

Home page will display when load complete (~1 minute).

NOTE

Expect PCS FDA 'CDH MDM N1-1  
Detected RT Fail MDM N1-2 - PMA1'.

Node 1: C&DH: MDM N1-1

Primary NCS MDM Node1

'MDM Major State'

√State - Primary

```
*****
*   If State not Primary or no N1-1 TLM   *
*                                           *
*   √MCC                                   *
*****
```

5. REMOVE POWER FROM N1-2 MDM AT RPC

NOTE

Expect PCS FDA (LED and message only)  
when MDM power removed.

Node 1: C&DH: MDM N1-2

Secondary NCS MDM Node1

'RPCM N1RS2 C'

sel RPC 13

**cmd** Open **Execute**

√Position - Op

PCS

6. DISABLE RT DEVICES I/O ON EPS BUSES

Node 1: C&DH: MDM N1-1

Primary NCS MDM Node1

sel UB EPS\_N1 23

sel RT Status

**cmd** Inhib\_RPCM\_N1RS2\_A **Execute**  
**cmd** Inhib\_RPCM\_N1RS2\_B **Execute**  
**cmd** Inhib\_RPCM\_N1RS2\_C **Execute**  
**cmd** Inhib\_RPCM\_Z13B\_A **Execute**  
**cmd** Inhib\_RPCM\_Z13B\_B **Execute**

PRIM\_EPS\_N1\_23\_RT Status

√RT Inhibit 11, 12, 18, 19, 20 (five) - Inh

## 7. COMMAND FGB RACU 5 OFF

### NOTE

RACU commands sent from orbiter will not work if FGB relay matrix is in **MCC-M** command state (COMMANDING - INH). Crew can follow ground activities using the "If ENA" block below.

CRT

SM 204 FGB

√COMMANDING - INH (Moscow Commanding)

If COMMANDING - INH

**Crew** ↓ **MCC-H**: "Ready for RACU 5 Power Off."  
**MCC-H** ⇒ **MCC-M**: "Go for RACU 5 Power Off."

RUSSIAN GROUND	<u>AOS</u>	<u>LOS</u>
Pass 1	___/___:__:__	___/___:__:__
Pass 2	___/___:__:__	___/___:__:__

**MCC-M** ⇒ **MCC-H** ↑ crew: "RACU 5 Powered Off at  
 \_\_\_/\_\_\_:\_\_:\_\_ GMT."

If COMMANDING - ENA

**MCC-M** ⇒ **MCC-H**: "Go for RACU 5 Power Off."  
**MCC-H** ↑ crew: "Moscow GO for RACU 5 Power Off."

**On MCC GO:**

MCDS

SM 204 FGB

RACU 5 Power OFF VIA NCS - ITEM 6 EXEC  
 √RACU 5 Input Amps < 2.0 A  
 √Output Volts ~0.0 V  
 √RACU 5 Power Off - \*

PCS

nav FGB: EPS  
FGB: EPS: RACU Details  
**RACU Details**

sel Commands  
**cmd** RACU 5 - Off **Execute**  
√RACU 5 Converter - Off  
√RACU 5 Input Current < 2.0 A  
√Output Voltage ~0.0 V